



DESCRIPTION

These gentle but effective wipes will clean corrosion and other contaminants from battery terminals. The unique color indicator formula will turn from blue to pink in presence of acid, then turn back to blue once the acid is neutralized.

The neutralizing fluid on the wipes does not cause foaming action, and leaves a clean, protective barrier on the terminals and contact areas.

PRECAUTION

Wash thoroughly after handling. Wear eye protection, protective clothing, protective gloves. Take off contaminated clothing and wash before reuse.

IF ON SKIN: Wash with plenty of water.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

If skin irritation occurs: Get medical advice/attention. If eye irritation persists: Get medical advice/attention.

DISPOSAL

Offer empty container for recycling. If recycling is not available, discard container in trash. Do not flush wipes.

*For industrial and commercial use only.
For additional information, see Safety Data Sheet.*

TOTAL SOLUTIONS®

WET WIPES

BATTERY ACID CLEANING WIPES

Unique Color-Indicating
Formula

• EXTENDS THE LIFE AND
PERFORMANCE OF BATTERIES

WARNING

Causes skin irritation. Causes serious eye irritation.

KEEP OUT OF REACH OF CHILDREN

NET CONTENTS: 30

7" x 8" (17.78 cm x 20.32 cm) Premoistened Wipes

Manufactured By: Total Solutions®

PO Box 240014 • Milwaukee, WI 53224 • 1-800-743-6417

DIRECTIONS

Wipe the surface of the battery post, removing deposits. These wipes can also be used to remove corrosion on the connectors and battery trays. The blue wipe will turn pink in the presence of the acidic corrosion. Be sure to keep turning and scrubbing the area until the wipe turns back to its original blue color. This will indicate that the corrosion has been neutralized.

These wipes are only to be used on lead acid batteries.

DIRECTIONS FOR DISPENSING

1. Remove lid by lifting upward. Remove foil seal.
2. Pull towel from center of the roll and thread through "X" on the underside of the lid.
3. Close lid. Pull towel at 90° angle.
4. Snap hinged cap back into place to ensure towels stay moist.



NFPA® RATINGS

Health: 1; Flammability: 1; Reactivity: 0

CONTAINS/CAS NUMBER:

Water/7732-18-5; Potassium Carbonate/584-08-7; Sodium Carbonate/497-19-8; Thymol Blue/62625-21-2



Please Recycle.

Canister made from 25% post-consumer recycled plastic.

1525.013015